

Mighty Sun Guard Installation Instructions

Surface Preparation

- (1) Pressure wash the surface, and make sure to remove any dirt and grease. Apply primer and rust prevention coating on the metal surface before applying Mighty Sun Guard.
- (2) Thoroughly dry surface before application.

Mighty Sun Guard Preparation

Mix the product thoroughly.

It separates again in 30 minutes; stir it well before you apply.

Brush Application

Use a wider brush, 3" or larger.

Apply evenly at least 0.5mm thick. 2 coats are recommended.

Spray Gun Application

Stir product well; use the product soon after preparing.

Diameter of spray gun nozzle should be 3.8 mm to 4.5 mm.

Recommended air pressure is 8.5 Kg.

Standard Application Coverage

1 Pail is 14 Kg (19 liters) which covers approximately 25 m² (269 SF).

Thickness of the coating should be 0.56 Kg/ m² →500 to 600 microns.

Other notes

Add some water if Mighty Sun Guard starts to harden.

Rinse Spray Gun and Brush with clean water.

Always wear appropriate protective gear including protective eye wear. Seek medical attention immediately if Mighty Sun Guard gets in the eyes.